

NOTICE TO ALL AIRMEN OPERATING FROM SAUERDALE AIRFIELD

- 1. SAUERDALE AIRFIELD IS LOCATED WITHIN THE CONTROL ZONE OF JOSHUA NKOMO INTERNATIONAL AIRPORT – BULAWAYO [FVJN] AND IS SITUATED WITHIN CLASS C AIRSPACE.**
- 2. ALL AIRMEN MUST REQUEST APPROVAL FROM NKOMO APPROACH BEFORE COMMENCEMENT OF OPERATIONS FROM SAUERDALE AIRFIELD AND ALSO ADVISE NKOMO APPROACH WHEN OPERATIONS HAVE BEEN COMPLETED.**
- 3. AIRCRAFT SHALL BROADCAST INTENTIONS ON 118.7 MHz WHENEVER PREPARING TO GET AIRBORNE FROM SAUERDALE AIRFIELD.**
- 4. PILOTS-IN-COMMAND WHO ARE UNABLE TO ESTABLISH COMMUNICATION WITH NKOMO APPROACH PRIOR TO DEPARTURE FROM SAUERDALE AIRFIELD USING THE AIRCRAFT'S RADIO COMMUNICATION EQUIPMENT MUST THEN MAKE USE OF THE BASE RADIO SET LOCATED IN THE SAUERDALE AIRFIELD RADIO ROOM, OR BY TELEPHONE.**
- 5. PILOTS WHO ARE UNABLE TO ESTABLISH COMMUNICATION WITH NKOMO APPROACH AND OBTAIN PRIOR APPROVAL FOR OPERATIONS, ARE NOT PERMITTED TO TAKE OFF AND MUST REMAIN ON THE GROUND.**
- 6. ONLY THOSE HOLDING A VALID PILOT'S RADIO LICENCE MAY USE THE BASE RADIO SET AND MUST COMPLETE THE OPERATIONS LOG BOOK AND RECORD THEIR RADIOTELEPHONY LICENCE NUMBER THEREIN.**
- 7. AIRCRAFT SHALL GET AIRBORNE AND REMAIN IN THE CIRCUIT AT OR BELOW 5000 ft AND WILL REMAIN UNDER AIR TRAFFIC CONTROL FROM NKOMO APPROACH [FVJN] AT ALL TIMES.**
- 8. ALL AIR TRAFFIC DEPARTING FROM RUNWAY 13 SHALL CLIMB UP TO 5000 ft AND ENTER THE RIGHT-HAND CIRCUIT.**
- 9. THE PILOT-IN-COMMAND SHALL BROADCAST ON THE UNMANNED AERODROME FREQUENCY (118.7 MHz).**
- 10. ALL AIR TRAFFIC DEPARTING FROM RUNWAY 31 SHALL CLIMB UP TO 5000 ft AND ENTER THE LEFT-HAND CIRCUIT.**
- 11. THE PILOT-IN-COMMAND SHALL BROADCAST ON THE UNMANNED AERODROME FREQUENCY (118.7 MHz).**
- 12. ALL IFR TRAFFIC SHALL BE SEPARATED FROM TRAFFIC IN THE CIRCUIT AT SAUERDALE AIRFIELD.**
- 13. ALL VFR TRAFFIC SHALL BE GIVEN TRAFFIC INFORMATION AND ALSO REQUESTED TO BROADCAST ON 118.7 MHz.**

PILOTS WHO FAIL TO FULLY COMPLY WITH THESE INSTRUCTIONS COMMIT AN OFFENCE IN TERMS OF THE AERONAUTICAL LAWS OF ZIMBABWE



Civil Aviation
Authority of Zimbabwe

Bulawayo Light Sport Aircraft Club



Sauerdale Airfield

Douglasdale Rd, Bulawayo

20° 15' 3.09" S 28° 36' 36.86" E

CONTROLLED DOCUMENT
BLSAC # 001